airstar

QUICK START-UP

SIROCCO RANGE

1



2



3

4



5

6



7



8



USER'S GUIDE

airstar

QUICK BREAK-DOWN

SIROCCO RANGE

1



2

3

4



5

6

USER'S GUIDE

SAFETY WARNING

WIND SPEED

Bags on tripod stands are mandatory, for indoor or outdoor use. **12 kg/25 lbs per bag** are required, with the material of your choice (sand, steel shot, etc.).

Wind speed	Sirocco 300 LITE	Sirocco 500 LITE	Sirocco 700 POWER	Sirocco 1000 POWER	Sirocco 1300 POWER
3 bags or a minimum of 36 kg/75 lbs	0 to 80 km/h 0 to 49 mph	0 to 78 km/h 0 to 48 mph	0 to 68 km/h 0 to 42 mph	0 to 60 km/h 0 to 37 mph	0 to 50 km/h 0 to 31 mph
6 bags or a minimum of 72 kg/150 lbs	0 to 80 km/h* 0 to 49 mph*	78 to 80 km/h* 48 to 50 mph*	68 to 88 km/h* 42 to 54 mph*	60 to 76 km/h* 37 to 47 mph*	50 to 64 km/h* 31 to 39 mph*
Guy ropes AND 6 bags or a minimum of 72 kg/150 lbs	0 to 80 km/h* 0 to 49 mph*	80 km/h* 50 mph*	88 to 100 km/h* 54 to 62 mph*	76 to 100 km/h* 47 to 62 mph*	64 to 100 km/h* 39 to 62 mph*

P460-AC stand height: 4.60 m/15 ft. (*Indicative values for flat terrain and regular wind. In case of strong or gusty winds, use guy ropes and/or reduce the height of the stand.)
To ensure safety, Airstar recommends a maximum stand height of 4 m/13 ft.

www.airstar-light.com

July 24